

Putting with ClubHub

In order to detect the longest and the shortest putts, it's important to align the ClubHub™ correctly on the putter. When you attach the ClubHub™ to the putter, you'll want to make the long arm of the green "H" as parallel to the putter's club face as possible. Upside down is OK too. To illustrate the correct and incorrect way to position the ClubHub™, see the following pictures.



Correct: The green line of the "H" is parallel to the putter face.



Incorrect: The green line of the "H" is NOT parallel with the putter face.

Did you know our sensors have a highly sensitive impact detector to capture short putts?

Unlike other shots, we don't filter out putts from the same GPS location due to the possibility that we would filter out a real putt struck very near a previous putt.

These two things can combine to register extra putts if you bump the ground during your putt rehearsal swings.

To **prevent** extra putts, try the following:

When you make a rehearsal (practice) swing with your putter, swing the putter head above the turf.
Do not brush or bump the turf.

In the event you get an extra putt, you can easily delete it from List view by swiping left on the shot and confirming the **Delete** by touching the red button.

Shots can be deleted during the round or later via **TRACK PERFORMANCE**.

